AGE-VERIFIED / HEAD UNIT

ID first. Head only.

An age-verification vending head listed without its floor base. Published figures belong to

10*
SELECTIONS (FLOOR REF)

150*
MAX PIECES (FLOOR REF)

ID*
VERIFICATION DEVICE



LEFT-FACING	FRONT VIEW	RIGHT-FACING
Cedar	Cream / Deep Teal	Rosewood

Configured for your products.

Cedar, Lagoon and Rosewood finish options are shown on the genuine bound view.

PLACE THE EXPERIENCE IN CONTEXT

A useful stop in the daily flow.

Illustrative placement concepts show how the format could sit in a planned environment. They are not photographs of completed FCV installations.



Mounted age-check head

AUDIENCE

A verification head mounted inside licensed retail space.

ACCESS

Agree the mounting drawing, pack range and verifier flow.

SITE CHECK

Check collection clearance, reader position and access.



Forecourt verifier unit

An illustrative placement near amenities, not an installed project.



Restricted head point

An indoor concept beside circulation; agree access hours and approvals.

PUBLISHED MODEL DATA / CONFIRM THE SUPPLIED CONFIGURATION

A clearer view of the specification.

ID*
VERIFY DEVICE

10*
SELECTIONS (REF)

5x2*
LAYERS x SPRINGS (REF)

Cabinet + interface

Floor ref H	**1835/1850 mm**
Floor ref W	**700 mm**
Floor ref D	**315/319 mm**
Head dims	**Unresolved**

Loading + release

Mode	**Ambient**
Collection	**PUSH opening**
Verifier	**Device illustrated**
Mounting	**Per installation**



SCREEN-GATED VEND

The customer verifies ID, selects on the grid screen and collects

ELECTRICAL + INTERFACE

Ambient (floor refs)*

Published schedules are ambient full-height units; the head schedule is not separately published.

Head dims unresolved

COOLING + PACK FIT

Full-height refs only*

Ten selections and 150 pieces belong to the named floor units, not the head.

Head layout described; mounting, spring spacing and delivery clearance need confirming per build.

Published watts are not daily energy use.

The bound candidate is byte-identical to the m189 v2 file under a distinct m193 receipt — provenance retained, no merged record.

This record mirrors the m189 listing; both catalogue entries remain separate.

PUBLISHED CAPABILITY / SELECTED FITMENT

Digital at the front. Clear behind it.

Specify the customer experience and the fitted hardware separately. A published option is not a promise that every device is installed.

Customer experience

A payment reader is pictured on the head; fitted payment devices and providers are not verified. Agree the supplied device scope.

A configurable system

The verification flow gates the vend. Confirm the supplied verifier hardware, mounting and enabled payment options.

Payment methods + fitment

METHOD	PUBLISHED CAPABILITY	SELECTED SETUP
Cards	Not documented	Confirm terminal and provider
NFC / contactless	Not verified	Confirm enabled methods
QR / scan	Reader pictured*	Confirm fitted devices
Cash / banknotes **Coins** **Coin changer / change**	Payment hardware, provider scope and software licensing are specified in the quotation, not by imagery.	Do not assume devices are fitted or enabled. Confirm provider, currency and collection.

Confirm reader, currency, enabled methods, SIM/network, merchant onboarding, fees and refund process. MDB/DEX does not by itself confirm every device or provider. Agree software, reporting and inventory scope separately.

Published options to select

ID verify*
CONFIRM SELECTED FITMENT

Grid screen*
CONFIRM SELECTED FITMENT

PUSH collect*
CONFIRM SELECTED FITMENT

Head-only*
CONFIRM SELECTED FITMENT

Reader pictured*
CONFIRM SELECTED FITMENT

Payments: confirm
CONFIRM SELECTED FITMENT

PHOTOGRAPHED CONFIGURATION / AGREED LOADING PLAN

Map the flow. Test the vend.

Pictured layout: full-height selection grid with age-restriction badges above a PUSH collection panel and reader device on a slim base-free head; cream face with teal wave base.



FULL CABINET



1 Grid screen
2 Age badges
3 PUSH panel
4 Reader device
5 Teal wave
6 Slim head
7 Mount edge

SELECTION GRID HEAD

Numbered zones mark the photographed customer-flow stages.

Confirm the loading plan

HEAD MOUNT

The head ships without its floor base — confirm the installation drawing and mounting

SELECTION GRID

The screen grid is the only customer path on the head — confirm product tiles and the wake behaviour.

VERIFY FLOW

Exercise the ID-verification device end-to-end: wake, read, approve and release before trading.

SCHEDULE CHECK

Published 10-selection/150-piece figures belong to full-height units — do not quote them

Confirm the mounting drawing and exercise the verifier end-to-end before launch.

THREE WAYS TO OPERATE / PRICING TAILORED TO YOUR SITE

Choose your operating plan.

Select the responsibility split for your machine, products and service. Prices and the final terms are confirmed for your chosen setup.

01 / SELF-OPERATE

Own + operate

Pay 100% of the machine price upfront. Own the equipment and manage products and daily operation.

02 / FIXED MONTHLY FEE

Your products. FCV service.

You provide products. FCV handles agreed refilling, maintenance, technical and software support.

03 / FULLY MANAGED

FCV manages

Customer buys the machine. FCV owns products, sets retail prices, and manages restocking, technical/software support, maintenance and complaints.

RESPONSIBILITY	SELF-OPERATE	FIXED FEE	FCV MANAGED
Products	You	You	FCV
Retail prices	You	Agreed scope	FCV
Restocking	You	FCV in agreed scope	FCV
Care + software	Agree separately	FCV in agreed scope	FCV
Customer issues	You	Agreed scope	FCV

Fully managed: purchase and agreed share

MACHINE PURCHASE

100% Customer pays the agreed machine price in full. The customer owns the equipment.

GROSS-SALES SHARE: UP TO

25% The owner share of monthly gross sales is agreed by performance.

The contract term, machine ownership and operating responsibilities are confirmed before the managed agreement is finalised.

Monthly gross-sales share is agreed by sales performance, up to 25%. No minimum share or sales result is promised.

Pricing tailored to your setup.

Request a personalised quotation for your selected machine, configuration and operating plan.

Get pricing on WhatsApp

Contact FCV

Main website | This model | Google Maps